

DECORATO A MANO
HAND DECORATED


DIVA





BREAD PLATE / TEA SAUCER
PIATTO PANE / PIATTO TÈ

H 1.7 cm | W 17 cm | Wgt: 265 gr
H 0.67 in | W 6.69 in | Wgt: 0.58 lb
008RG00 FPT401010170G00134900
EAN 8026762038923 | UPC 197091038927




DESSERT PLATE
PIATTO DESSERT

H 2.4 cm | W 20 cm | Wgt: 366 gr
H 0.94 in | W 7.87 in | Wgt: 0.81 lb
008RG00 FPT110010200G00134900
EAN 8026762038763 | UPC 197091038767



DINNER PLATE
PIATTO PIANO

H 2.8 cm | W 27 cm | Wgt: 683 gr
H 1.1 in | W 10.63 in | Wgt: 1.51 lb
008RG00 FPT110010270G00134900
EAN 8026762038688 | UPC 197091038682



DINNER PLATE
PIATTO PIANO

H 2.6 cm | W 24 cm | Wgt: 528 gr
H 1.02 in | W 9.45 in | Wgt: 1.16 lb
008RG00 FPT110010240G00134900
EAN 8026762038848 | UPC 197091038842



SOUP PLATE
PIATTO FONDO

H 3.6 cm | W 24 cm | Wgt: 523 gr
H 1.42 in | W 9.45 in | Wgt: 1.15 lb
008RG00 FPT210010240G00134900
EAN 8026762039005 | UPC 197091039009



SUGAR BOWL / BUTTER PLATE
COPERCHIO ZUCCHIERIERA / PIATTO BURRO

H 2.3 cm | W 10 cm | C 730 ml | Wgt: 124 gr
H 0.91 in | W 3.94 in | C 24.68 fl.oz | Wgt: 0.27 lb
008RG00 FZU002010100G00134900
EAN 8026762040735 | UPC 197091040739



PICKLE DISH
RAVIERA

H 3.8 cm | W 21.6 cm | Wgt: 503 gr
H 1.5 in | W 8.5 in | Wgt: 1.11 lb
008RG00 FRV000010215G00134900
EAN 8026762040650 | UPC 197091040654



TUREEN AND SALAD BOWL
ZUPPIERA E INSALATIERA

H 8 cm | W 24 cm | C 26000 ml | Wgt: 1305 gr
H 3.15 in | W 9.45 in | C 879.15 fl.oz | Wgt: 2.88 lb
008RG00 FZP001012600G00134900
EAN 8026762044948 | UPC 197091044942




FRUIT BOWL
COPPETTA

H 5.4 cm | W 10 cm | C 2450 ml | Wgt: 273 gr
H 2.13 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.6 lb
008RG00 FZU001010245G00134900
EAN 8026762040575 | UPC 197091040579



**COFFEE CUP
TAZZA CAFFÈ**

H 5.3 cm | W 6 cm | C 850 ml | Wgt: 110 gr
H 2.09 in | W 2.36 in | C 28.74 fl.oz | Wgt: 0.24 lb
008RG00 FTZ301010085G00134900
EAN 8026762040810 | UPC 197091040814



**COFFEE SAUCER
PIATTO CAFFÈ**

H 1.6 cm | W 12.5 cm | Wgt: 131 gr
H 0.63 in | W 4.92 in | Wgt: 0.29 lb
008RG00 FPT301010125G00134900
EAN 8026762040896 | UPC 197091040890



**TEA CUP
TAZZA TÈ**

H 5.4 cm | W 9.5 cm | C 2450 ml | Wgt: 281 gr
H 2.13 in | W 3.74 in | C 82.84 fl.oz | Wgt: 0.62 lb
008RG00 FTZ401010245G00134900
EAN 8026762041138 | UPC 197091041132



**TEAPOT
TEIERA**

H 11.2 cm | W 13 cm | C 7700 ml | Wgt: 755 gr
H 4.41 in | W 5.12 in | C 260.36 fl.oz | Wgt: 1.66 lb
008RG00 FTE400010770G00134900
EAN 8026762041213 | UPC 197091041217



**COFFEEPOT
CAFFETTIERA**

H 11.4 cm | W 9.5 cm | C 5070 ml | Wgt: 458 gr
H 4.49 in | W 3.74 in | C 171.43 fl.oz | Wgt: 1.01 lb
008RG00 FCF300010500G00134900
EAN 8026762040971 | UPC 197091040975



**MILK JUG
LATTIERA**

H 7 cm | W 10 cm | C 3050 ml | Wgt: 322 gr
H 2.76 in | W 3.94 in | C 103.13 fl.oz | Wgt: 0.71 lb
008RG00 FLT000010300G00134900
EAN 8026762041657 | UPC 197091041651




**SUGAR BOWL
ZUCCHIERERA**

H 6.4 cm | W 10 cm | C 2450 ml | Wgt: 397 gr
H 2.52 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.88 lb
008RG00 FZU000010245G00134900
EAN 8026762041732 | UPC 197091041736



**TUREEN / FRUIT BOWL
COPERCHIO ZUPPIERA / FRUTTIERA**
H 3.9 cm | W 24 cm | C 9800 ml | Wgt: 800 gr
H 1.54 in | W 9.45 in | C 331.37 fl.oz | Wgt: 1.76 lb
008RG00 FZP002010240G00134900
EAN 8026762045051 | UPC 197091045055



**RECTANGULAR PLATTER
VASSOIO RETTANGOLARE**

H 2.8 cm | W 28.8 cm | Wgt: 540 gr
H 1.1 in | W 11.34 in | Wgt: 1.19 lb
136RG00 FVS140LX28XG00134900
EAN 8026762043347 | UPC 197091043341



**TEA SET FOR 2
SET TÈ PER 2**

C 2450 ml | Wgt: 1092 gr
C 82.84 fl.oz | Wgt: 2.41 lb
008RG00 FW4401LXGENG00134900
EAN 8026762043071 | UPC 197091043075




**COFFEE SET FOR 2
SET CAFFÈ PER 2**

C 850 ml | Wgt: 482 gr
C 28.74 fl.oz | Wgt: 1.06 lb
008RG00 FW4301LXGENG00134900
EAN 8026762043033 | UPC 197091043037



**CHANGE TRAY
SVUOTATASCHE**

H 4.4 cm | W 13.5 cm | Wgt: 285 gr
H 1.73 in | W 5.31 in | Wgt: 0.63 lb
172RG01 FCP220LX13XG00134900
EAN 8026762043224 | UPC 197091043228



**ROUND CHANGE TRAY
SVUOTATASCHE ROTONDO**

H 3 cm | W 17 cm | Wgt: 383 gr
H 1.18 in | W 6.69 in | Wgt: 0.84 lb
017RG00 FCO108LX0170G00134900
EAN 8026762043422 | UPC 197091043426



**BOX WITH COVER
SCATOLA**

H 6.3 cm | W 8.2 cm | Wgt: 160 gr
H 2.48 in | W 3.23 in | Wgt: 0.35 lb
017RG00 FCO400LX0080G00134900
EAN 8026762043545 | UPC 197091043549



BREAD PLATE / TEA SAUCER
PIATTO PANE / PIATTO TÈ

H 1.7 cm | W 17 cm | Wgt: 265 gr
H 0.67 in | W 6.69 in | Wgt: 0.58 lb
008RG00 FPT401010170G00134901
EAN 8026762038930 | UPC 197091038934



DESSERT PLATE
PIATTO DESSERT

H 2.4 cm | W 20 cm | Wgt: 366 gr
H 0.94 in | W 7.87 in | Wgt: 0.81 lb
008RG00 FPT110010200G00134901
EAN 8026762038770 | UPC 197091038774



DINNER PLATE
PIATTO PIANO

H 2.8 cm | W 27 cm | Wgt: 683 gr
H 1.1 in | W 10.63 in | Wgt: 1.51 lb
008RG00 FPT110010270G00134901
EAN 8026762038695 | UPC 197091038699



DINNER PLATE
PIATTO PIANO

H 2.6 cm | W 24 cm | Wgt: 528 gr
H 1.02 in | W 9.45 in | Wgt: 1.16 lb
008RG00 FPT110010240G00134901
EAN 8026762038855 | UPC 197091038859



SOUP PLATE
PIATTO FONDO

H 3.6 cm | W 24 cm | Wgt: 523 gr
H 1.42 in | W 9.45 in | Wgt: 1.15 lb
008RG00 FPT210010240G00134901
EAN 8026762039012 | UPC 197091039016



SUGAR BOWL / BUTTER PLATE
COPERCHIO ZUCCHIERIERA / PIATTO BURRO

H 2.3 cm | W 10 cm | C 730 ml | Wgt: 124 gr
H 0.91 in | W 3.94 in | C 24.68 fl.oz | Wgt: 0.27 lb
008RG00 FZU002010100G00134901
EAN 8026762040742 | UPC 197091040746



PICKLE DISH
RAVIERA

H 3.8 cm | W 21.6 cm | Wgt: 503 gr
H 1.5 in | W 8.5 in | Wgt: 1.11 lb
008RG00 FRV000010215G00134901
EAN 8026762040667 | UPC 197091040661



TUREEN AND SALAD BOWL
ZUPPIERA E INSALATIERA

H 8 cm | W 24 cm | C 2600 ml | Wgt: 1305 gr
H 3.15 in | W 9.45 in | C 879.15 fl.oz | Wgt: 2.88 lb
008RG00 FZP001012600G00134901
EAN 8026762044955 | UPC 197091044959



FRUIT BOWL
COPPETTA

H 5.4 cm | W 10 cm | C 2450 ml | Wgt: 273 gr
H 2.13 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.6 lb
008RG00 FZU001010245G00134901
EAN 8026762040582 | UPC 197091040586



**COFFEE CUP
TAZZA CAFFÈ**

H 5.3 cm | W 6 cm | C 850 ml | Wgt: 110 gr
H 2.09 in | W 2.36 in | C 28.74 fl.oz | Wgt: 0.24 lb
008RG00 FTZ301010085G00134901
EAN 8026762040827 | UPC 197091040821



**COFFEE SAUCER
PIATTO CAFFÈ**

H 1.6 cm | W 12.5 cm | Wgt: 131 gr
H 0.63 in | W 4.92 in | Wgt: 0.29 lb
008RG00 FPT301010125G00134901
EAN 8026762040902 | UPC 197091040906



**TEA CUP
TAZZA TÈ**

H 5.4 cm | W 9.5 cm | C 2450 ml | Wgt: 281 gr
H 2.13 in | W 3.74 in | C 82.84 fl.oz | Wgt: 0.62 lb
008RG00 FTZ401010245G00134901
EAN 8026762041145 | UPC 197091041149



**TEAPOT
TEIERA**

H 11.2 cm | W 13 cm | C 7700 ml | Wgt: 755 gr
H 4.41 in | W 5.12 in | C 260.36 fl.oz | Wgt: 1.66 lb
008RG00 FTE400010770G00134901
EAN 8026762041220 | UPC 197091041224



**COFFEEPOT
CAFFETTIERA**

H 11.4 cm | W 9.5 cm | C 5070 ml | Wgt: 458 gr
H 4.49 in | W 3.74 in | C 171.43 fl.oz | Wgt: 1.01 lb
008RG00 FCF300010500G00134901
EAN 8026762040988 | UPC 197091040982



**MILK JUG
LATTIERA**

H 7 cm | W 10 cm | C 3050 ml | Wgt: 322 gr
H 2.76 in | W 3.94 in | C 103.13 fl.oz | Wgt: 0.71 lb
008RG00 FLT000010300G00134901
EAN 8026762041664 | UPC 197091041668



**SUGAR BOWL
ZUCCHIERERA**

H 6.4 cm | W 10 cm | C 2450 ml | Wgt: 397 gr
H 2.52 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.88 lb
008RG00 FZU000010245G00134901
EAN 8026762041749 | UPC 197091041743



**TUREEN / FRUIT BOWL
COPERCHIO ZUPPIERA / FRUTTIERA**
H 3.9 cm | W 24 cm | C 9800 ml | Wgt: 800 gr
H 1.54 in | W 9.45 in | C 331.37 fl.oz | Wgt: 1.76 lb
008RG00 FZP002010240G00134901
EAN 8026762045068 | UPC 197091045062



**RECTANGULAR PLATTER
VASSOIO RETTANGOLARE**

H 2.8 cm | W 28.8 cm | Wgt: 540 gr
H 1.1 in | W 11.34 in | Wgt: 1.19 lb
136RG00 FVS140LX28XG00134901
EAN 8026762043354 | UPC 197091043358



**TEA SET FOR 2
SET TÈ PER 2**

C 2450 ml | Wgt: 1092 gr
C 82.84 fl.oz | Wgt: 2.41 lb
008RG00 FW4401LXGENG00134901
EAN 8026762043088 | UPC 197091043082



**COFFEE SET FOR 2
SET CAFFÈ PER 2**

C 850 ml | Wgt: 482 gr
C 28.74 fl.oz | Wgt: 1.06 lb
008RG00 FW4301LXGENG00134901
EAN 8026762043040 | UPC 197091043044



**CHANGE TRAY
SVUOTATASCHE**

H 4.4 cm | W 13.5 cm | Wgt: 285 gr
H 1.73 in | W 5.31 in | Wgt: 0.63 lb
172RG01 FCP220LX13XG00134901
EAN 8026762043231 | UPC 197091043235



**ROUND CHANGE TRAY
SVUOTATASCHE ROTONDO**

H 3 cm | W 17 cm | Wgt: 383 gr
H 1.18 in | W 6.69 in | Wgt: 0.84 lb
017RG00 FCO108LX0170G00134901
EAN 8026762043439 | UPC 197091043433



**BOX WITH COVER
SCATOLA**

H 6.3 cm | W 8.2 cm | Wgt: 160 gr
H 2.48 in | W 3.23 in | Wgt: 0.35 lb
017RG00 FCO400LX0080G00134901
EAN 8026762043552 | UPC 197091043556



BREAD PLATE / TEA SAUCER
PIATTO PANE / PIATTO TÈ

H 1.7 cm | W 17 cm | Wgt: 265 gr
H 0.67 in | W 6.69 in | Wgt: 0.58 lb
008RG00 FPT401010170G00134902
EAN 8026762038947 | UPC 197091038941



DESSERT PLATE
PIATTO DESSERT

H 2.4 cm | W 20 cm | Wgt: 366 gr
H 0.94 in | W 7.87 in | Wgt: 0.81 lb
008RG00 FPT110010200G00134902
EAN 8026762038787 | UPC 197091038781



DINNER PLATE
PIATTO PIANO

H 2.8 cm | W 27 cm | Wgt: 683 gr
H 1.1 in | W 10.63 in | Wgt: 1.51 lb
008RG00 FPT110010270G00134902
EAN 8026762038701 | UPC 197091038705



DINNER PLATE
PIATTO PIANO

H 2.6 cm | W 24 cm | Wgt: 528 gr
H 1.02 in | W 9.45 in | Wgt: 1.16 lb
008RG00 FPT110010240G00134902
EAN 8026762038862 | UPC 197091038866



SOUP PLATE
PIATTO FONDO

H 3.6 cm | W 24 cm | Wgt: 523 gr
H 1.42 in | W 9.45 in | Wgt: 1.15 lb
008RG00 FPT210010240G00134902
EAN 8026762039029 | UPC 197091039023



SUGAR BOWL / BUTTER PLATE
COPERCHIO ZUCCHERIERA / PIATTO BURRO

H 2.3 cm | W 10 cm | C 730 ml | Wgt: 124 gr
H 0.91 in | W 3.94 in | C 24.68 fl.oz | Wgt: 0.27 lb
008RG00 FZU002010100G00134902
EAN 8026762040759 | UPC 197091040753



PICKLE DISH
RAVIERA

H 3.8 cm | W 21.6 cm | Wgt: 503 gr
H 1.5 in | W 8.5 in | Wgt: 1.11 lb
008RG00 FRV000010215G00134902
EAN 8026762040674 | UPC 197091040678



TUREEN AND SALAD BOWL
ZUPPIERA E INSALATIERA

H 8 cm | W 24 cm | C 2600 ml | Wgt: 1305 gr
H 3.15 in | W 9.45 in | C 879.15 fl.oz | Wgt: 2.88 lb
008RG00 FZP001012600G00134902
EAN 8026762044962 | UPC 197091044966



FRUIT BOWL
COPPETTA

H 5.4 cm | W 10 cm | C 2450 ml | Wgt: 273 gr
H 2.13 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.6 lb
008RG00 FZU001010245G00134902
EAN 8026762040599 | UPC 197091040593



**COFFEE CUP
TAZZA CAFFÈ**

H 5.3 cm | W 6 cm | C 850 ml | Wgt: 110 gr
H 2.09 in | W 2.36 in | C 28.74 fl.oz | Wgt: 0.24 lb
008RG00 FTZ301010085G00134902
EAN 8026762040834 | UPC 197091040838



**COFFEE SAUCER
PIATTO CAFFÈ**

H 1.6 cm | W 12.5 cm | Wgt: 131 gr
H 0.63 in | W 4.92 in | Wgt: 0.29 lb
008RG00 FPT301010125G00134902
EAN 8026762040919 | UPC 197091040913



**TEA CUP
TAZZA TÈ**

H 5.4 cm | W 9.5 cm | C 2450 ml | Wgt: 281 gr
H 2.13 in | W 3.74 in | C 82.84 fl.oz | Wgt: 0.62 lb
008RG00 FTZ401010245G00134902
EAN 8026762041152 | UPC 197091041156



**TEAPOT
TEIERA**

H 11.2 cm | W 13 cm | C 7700 ml | Wgt: 755 gr
H 4.41 in | W 5.12 in | C 260.36 fl.oz | Wgt: 1.66 lb
008RG00 FTE400010770G00134902
EAN 8026762041237 | UPC 197091041231



**COFFEEPOT
CAFFETTIERA**

H 11.4 cm | W 9.5 cm | C 5070 ml | Wgt: 458 gr
H 4.49 in | W 3.74 in | C 171.43 fl.oz | Wgt: 1.01 lb
008RG00 FCF300010500G00134902
EAN 8026762040995 | UPC 197091040999



**MILK JUG
LATTIERA**

H 7 cm | W 10 cm | C 3050 ml | Wgt: 322 gr
H 2.76 in | W 3.94 in | C 103.13 fl.oz | Wgt: 0.71 lb
008RG00 FLT000010300G00134902
EAN 8026762041671 | UPC 197091041675



**SUGAR BOWL
ZUCCHIERERA**

H 6.4 cm | W 10 cm | C 2450 ml | Wgt: 397 gr
H 2.52 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.88 lb
008RG00 FZU000010245G00134902
EAN 8026762041756 | UPC 197091041750



**TUREEN / FRUIT BOWL
COPERCHIO ZUPPIERA / FRUTTIERA**

H 3.9 cm | W 24 cm | C 9800 ml | Wgt: 800 gr
H 1.54 in | W 9.45 in | C 331.37 fl.oz | Wgt: 1.76 lb
008RG00 FZP002010240G00134902
EAN 8026762045075 | UPC 197091045079



**RECTANGULAR PLATTER
VASSOIO RETTANGOLARE**

H 2.8 cm | W 28.8 cm | Wgt: 540 gr
H 1.1 in | W 11.34 in | Wgt: 1.19 lb
136RG00 FVS140LX28XG00134902
EAN 8026762043361 | UPC 197091043365




**TEA SET FOR 2
SET TÈ PER 2**

C 2450 ml | Wgt: 1092 gr
C 82.84 fl.oz | Wgt: 2.41 lb
008RG00 FW4401LXGENG00134902
EAN 8026762043095 | UPC 197091043099



**COFFEE SET FOR 2
SET CAFFÈ PER 2**

C 850 ml | Wgt: 482 gr
C 28.74 fl.oz | Wgt: 1.06 lb
008RG00 FW4301LXGENG00134902
EAN 8026762043057 | UPC 197091043051



**CHANGE TRAY
SVUOTATASCHE**

H 4.4 cm | W 13.5 cm | Wgt: 285 gr
H 1.73 in | W 5.31 in | Wgt: 0.63 lb
172RG01 FCP220LX13XG00134902
EAN 8026762043248 | UPC 197091043242



**ROUND CHANGE TRAY
SVUOTATASCHE ROTONDO**

H 3 cm | W 17 cm | Wgt: 383 gr
H 1.18 in | W 6.69 in | Wgt: 0.84 lb
017RG00 FCO108LX0170G00134902
EAN 8026762043446 | UPC 197091043440



**BOX WITH COVER
SCATOLA**

H 6.3 cm | W 8.2 cm | Wgt: 160 gr
H 2.48 in | W 3.23 in | Wgt: 0.35 lb
017RG00 FCO400LX0080G00134902
EAN 8026762043569 | UPC 197091043563



BREAD PLATE / TEA SAUCER
PIATTO PANE / PIATTO TÈ

H 1.7 cm | W 17 cm | Wgt: 265 gr
H 0.67 in | W 6.69 in | Wgt: 0.58 lb
008RG00 FPT401010170G00134903
EAN 8026762038954 | UPC 197091038958



DESSERT PLATE
PIATTO DESSERT

H 2.4 cm | W 20 cm | Wgt: 366 gr
H 0.94 in | W 7.87 in | Wgt: 0.81 lb
008RG00 FPT110010200G00134903
EAN 8026762038794 | UPC 197091038798



DINNER PLATE
PIATTO PIANO

H 2.8 cm | W 27 cm | Wgt: 683 gr
H 1.1 in | W 10.63 in | Wgt: 1.51 lb
008RG00 FPT110010270G00134903
EAN 8026762038718 | UPC 197091038712



DINNER PLATE
PIATTO PIANO

H 2.6 cm | W 24 cm | Wgt: 528 gr
H 1.02 in | W 9.45 in | Wgt: 1.16 lb
008RG00 FPT110010240G00134903
EAN 8026762038879 | UPC 197091038873



SOUP PLATE
PIATTO FONDO

H 3.6 cm | W 24 cm | Wgt: 523 gr
H 1.42 in | W 9.45 in | Wgt: 1.15 lb
008RG00 FPT210010240G00134903
EAN 8026762039036 | UPC 197091039036



SUGAR BOWL / BUTTER PLATE
COPERCHIO ZUCCHERIERA / PIATTO BURRO

H 2.3 cm | W 10 cm | C 730 ml | Wgt: 124 gr
H 0.91 in | W 3.94 in | C 24.68 fl.oz | Wgt: 0.27 lb
008RG00 FZU002010100G00134903
EAN 8026762040766 | UPC 197091040760



PICKLE DISH
RAVIERA

H 3.8 cm | W 21.6 cm | Wgt: 503 gr
H 1.5 in | W 8.5 in | Wgt: 1.11 lb
008RG00 FRV000010215G00134903
EAN 8026762040681 | UPC 197091040685



TUREEN AND SALAD BOWL
ZUPPIERA E INSALATIERA

H 8 cm | W 24 cm | C 2600 ml | Wgt: 1305 gr
H 3.15 in | W 9.45 in | C 879.15 fl.oz | Wgt: 2.88 lb
008RG00 FZP001012600G00134903
EAN 8026762044979 | UPC 197091044973



FRUIT BOWL
COPPETTA

H 5.4 cm | W 10 cm | C 2450 ml | Wgt: 273 gr
H 2.13 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.6 lb
008RG00 FZU001010245G00134903
EAN 8026762040605 | UPC 197091040609



**COFFEE CUP
TAZZA CAFFÈ**

H 5.3 cm | W 6 cm | C 850 ml | Wgt: 110 gr
H 2.09 in | W 2.36 in | C 28.74 fl.oz | Wgt: 0.24 lb
008RG00 FTZ301010085G00134903
EAN 8026762040841 | UPC 197091040845



**COFFEE SAUCER
PIATTO CAFFÈ**

H 1.6 cm | W 12.5 cm | Wgt: 131 gr
H 0.63 in | W 4.92 in | Wgt: 0.29 lb
008RG00 FPT301010125G00134903
EAN 8026762040926 | UPC 197091040920



**TEA CUP
TAZZA TÈ**

H 5.4 cm | W 9.5 cm | C 2450 ml | Wgt: 281 gr
H 2.13 in | W 3.74 in | C 82.84 fl.oz | Wgt: 0.62 lb
008RG00 FTZ401010245G00134903
EAN 8026762041169 | UPC 197091041163



**TEAPOT
TEIERA**

H 11.2 cm | W 13 cm | C 7700 ml | Wgt: 755 gr
H 4.41 in | W 5.12 in | C 260.36 fl.oz | Wgt: 1.66 lb
008RG00 FTE400010770G00134903
EAN 8026762041244 | UPC 197091041248



**COFFEEPOT
CAFFETTIERA**

H 11.4 cm | W 9.5 cm | C 5070 ml | Wgt: 458 gr
H 4.49 in | W 3.74 in | C 171.43 fl.oz | Wgt: 1.01 lb
008RG00 FCF300010500G00134903
EAN 8026762041008 | UPC 197091041002



**MILK JUG
LATTIERA**

H 7 cm | W 10 cm | C 3050 ml | Wgt: 322 gr
H 2.76 in | W 3.94 in | C 103.13 fl.oz | Wgt: 0.71 lb
008RG00 FLT000010300G00134903
EAN 8026762041688 | UPC 197091041682



**SUGAR BOWL
ZUCCHIERERA**

H 6.4 cm | W 10 cm | C 2450 ml | Wgt: 397 gr
H 2.52 in | W 3.94 in | C 82.84 fl.oz | Wgt: 0.88 lb
008RG00 FZU000010245G00134903
EAN 8026762041763 | UPC 197091041767



**TUREEN / FRUIT BOWL
COPERCHIO ZUPPIERA / FRUTTIERA**
H 3.9 cm | W 24 cm | C 9800 ml | Wgt: 800 gr
H 1.54 in | W 9.45 in | C 331.37 fl.oz | Wgt: 1.76 lb
008RG00 FZP002010240G00134903
EAN 8026762045082 | UPC 197091045086



**RECTANGULAR PLATTER
VASSOIO RETTANGOLARE**

H 2.8 cm | W 28.8 cm | Wgt: 540 gr
H 1.1 in | W 11.34 in | Wgt: 1.19 lb
136RG00 FVS140LX28XG00134903
EAN 8026762043378 | UPC 197091043372



**TEA SET FOR 2
SET TÈ PER 2**

C 2450 ml | Wgt: 1092 gr
C 82.84 fl.oz | Wgt: 2.41 lb
008RG00 FW4401LXGENG00134903
EAN 8026762043101 | UPC 197091043105



**COFFEE SET FOR 2
SET CAFFÈ PER 2**

C 850 ml | Wgt: 482 gr
C 28.74 fl.oz | Wgt: 1.06 lb
008RG00 FW4301LXGENG00134903
EAN 8026762043064 | UPC 197091043068



**CHANGE TRAY
SVUOTATASCHE**

H 4.4 cm | W 13.5 cm | Wgt: 285 gr
H 1.73 in | W 5.31 in | Wgt: 0.63 lb
172RG01 FCP220LX13XG00134903
EAN 8026762043255 | UPC 197091043259



**ROUND CHANGE TRAY
SVUOTATASCHE ROTONDO**

H 3 cm | W 17 cm | Wgt: 383 gr
H 1.18 in | W 6.69 in | Wgt: 0.84 lb
017RG00 FCO108LX0170G00134903
EAN 8026762043453 | UPC 197091043457



**BOX WITH COVER
SCATOLA**

H 6.3 cm | W 8.2 cm | Wgt: 160 gr
H 2.48 in | W 3.23 in | Wgt: 0.35 lb
017RG00 FCO400LX0080G00134903
EAN 8026762043576 | UPC 197091043570